For detailed Warranty Instructions and Information visit: http://www.hmdxaudio.com/products/jam-wireless-portable-speaker.html. To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-753-3000 or email cservice@hmdxaudio.com for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am-7:00pm EST Monday-Friday.

Por manual de instrucciones e Información de garantía en español visitenos en www.hmdxaudio.com HMDX Jam and HMDX are trademarks of HMDX. ©2013 HMDX. All Rights Reserved. IB-HXHP610



PLEASE TAKE A MOMENT NOW AND REGISTER YOUR PRODUCT AT:

www.hmdxaudio.com

Your valuable input will help us create even better products in the future.

WIRELESS STEREO HEADPHONES
USER GUIDE AND WARRANTY INFORMATION

Thank you for spreading the Jam and purchasing the HMDX Jam Fusion Wireless Headphones. Be sure to check out the entire JAM product line on our website: www.hmdxaudio.com — Where there's a Jam there's a party!

Package Contents



Jam Fusion



Pouch



Cable



Charging the Unit

Allow approximately 3 hours for a full charge. Can be charged by using the USB to Micro USB cord (included) through computer or AC adapter with USB jack (not included).

NOTE:

- Battery will last up to 6 hours when connected wirelessly. If battery is depleted you can still listen to music through the AUX line-in jack.
- 3 tones will sound every 40 seconds when less than 10% battery life remains.

| Indicators | | | |
|----------------------|---------------|--|--|
| Battery Indicator | Status | | |
| Solid RED | Charging | | |
| Solid BLUE | Fully Charged | | |
| | | | |

| Bluetooth® Indicator | Status |
|---|------------------------|
| Quickly Flashes BLUE Slowly Flashes BLUE | Pairing Mode Paired |
| | |

Controls

- 1. Line-In Audio Jack
- Jam² Pairing Switch
 Forward
- 4. Volume Up
- 5. Power Button
- 6. Play/Pause
- 7. Volume Down
- 8. Reverse
- Battery Status & Bluetooth[®] Indicator
- Bluetooth® Indicator

 10. USB Charging Port



Pairing a Single Jam Fusion Headphone

- 1. Make sure your device has Bluetooth® capability.
- 2. Make sure Jam² pairing switch is in single position (see Fig. 2).
- Press and hold power button for 5 seconds; indicator will begin to flash.
- Pair your device with the unit by selecting Jam Fusion from your Bluetooth[®] listings.
- 5. Press play and use controls on the unit to adjust desired volume, forward to next track or repeat track.

NOTE:

- Once you have successfully paired your device, you may not need to repeat the above steps. Please ensure the AUX cable is unplugged and your device has been Bluetooth[®] enabled.
- When pairing with a computer, please consult your computer manufacturer for Bluetooth® pairing instructions and/or the latest Bluetooth® Drivers.
- A pairing code is not required.

FIG. 2



Pairing 2 Jam Fusion Headphones

- Pair one headphone to your device by following the single pairing instructions.
- Move the Jam² pairing switch to the Jam² position on first headphone (see Fig. 3).
- 3. On the second headphone, move Jam² switch to the Jam² position and power on.
 4. The Bluetooth® indicator light will flash quickly until the units are paired. Once paired you will hear a hint tone and the Bluetooth®

indicator will slowly flash blue. **NOTE:** Jam² indicator will flash white when successfully paired.



Listening to your device through Auxiliary Line-In Audio Jack

- Connect AUX cable to the headphone or line-out jack of an audio device and plug the other end of the cable into the line-in audio jack on the unit.
- Press PLAY on device and use device controls to adjust volume or FWD/RVS tracks.

NOTE:

- Auxiliary line-in is a passive feature and does not require the power to be on.
- When listening through auxiliary line-in, the controls on the Fusion are disabled, always use the controls on your device.

Built-In Speakerphone

The Jam Fusion is equipped with a built-in speakerphone, for easy hands free talking:

1. Make sure the Jam Fusion has been successfully paired with your device.

2. To answer a call, simply press any button when you hear a ringtone.

3. To end call, press any button except +/- Volume buttons. **NOTE:**

When an incoming or outgoing call is detected, the Fusion will pause the music and a ringtone will sound. After the call is terminated, the music will resume to play automatically where it left off.
When making a call, use your phone to dial.

• To refuse an incoming call press and hold any button for 3 seconds.

 If the Jam Fusion is connected to the AUX cable when an incoming call is detected, use your phone to answer or refuse the call

Maintenance

Only use a soft dry cloth to clean the enclosure of the unit. NEVER use liquids or abrasive cleaner to clean.

FCC Warning

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference

that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by HMDX could void the user's authority to operate the equipment.

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

WARNING:

- Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.

- HMDX is not liable for any damage caused to Smartphones, iPod/MP3 player or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Not for use by children. THIS IS NOT A TOY.
 Never operate this product if it has a damaged cord, plug, cable

• Do not submerge into water or any other liquid.

- or housing.

 Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.
- This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local sate, providence and country guidelines.