

Where There's A Jam, There's A Party!™

www.jamaudio.com



USER GUIDE AND WARRANTY INFORMATION

HX-P710

READ UP.

PARTY DOWN.

### HEY. HAVE WE SEEN YOU HERE BEFORE?

Register your speaker at [www.jamaudio.com](http://www.jamaudio.com). Information about where you bought them and how you're using them is like gold for the people who make these speakers. Do them a solid, will ya?

Por manual de instrucciones e información de garantía en español visitenos en [www.jamaudio.com](http://www.jamaudio.com)

There are lots of cool Jam speakers. Check them all out at [www.jamaudio.com](http://www.jamaudio.com)


### PACKAGE CONTENTS



### JUST CHARGE IT

Charging the speaker is so easy you've probably figured it out by now, but just in case, you've got two options: your computer or a wall outlet.

1. The cord that came with the speaker—the one with the USB on one end and the Micro USB on the other—will work with your computer.




2. If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adapter, including the one for your cell.



Now go get ready for an epic night while your speaker does too. It needs about 3 hours of me time to be fully charged for 8 hours of party time.


### CONTROL YOUR DESTINY...

1. That's the power button, press and hold for 5 seconds to power on
2. Push it to play, push it again to pause
3. That light lets you know when Bluetooth has the hook-up
4. Skip back a track or jam on to the next song
5. Turn the music up
6. Carabiner



### OR AT LEAST YOUR SPEAKER

7. Check out how much juice is in the battery
8. Turn the music down (Wait, why do you need to turn it down?)
9. It speaks too. Toggle between languages here
10. The power cord goes here
11. Hook it up old-school
12. Language Selector Pin



### BLUETOOTH® CONNECTION: IT'S A SETUP

Like any amazing couple, this one starts with a connection—one between your device and the speaker's Bluetooth.

Here's how it works:

1. We know you're probably going to think, "derp" with this one, but we have to say it: Make sure the smartphone, tablet or computer you want to hook up to the speaker has Bluetooth. (There. We got that out of the way.)
2. Turn on the speaker and look for the little blinking light.

You're probably only going to have to do this once, unless your device goes through a major I-just-dropped-it-in-the-pool kind of reboot. The device and Bluetooth will find each other every time just as long as the speaker is set to Bluetooth and your device's Bluetooth is, you know—on.

If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company.

3. Do whatever your device needs you to do on its end. (We don't know what you're using. We're not spies.)
4. Look for Jam Street in your device's Bluetooth list or click YES—whatever pops up on your device—and BAM! you're connected.
5. Now hit PLAY on your speaker and crank it up—or down if you're lame.

Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code.


Press and hold PLAY/PAUSE for 5 seconds to activate pairing mode.

Note: If you turn on your Jam Street but haven't started the party yet, it will automatically power off after 2 minutes of unpaired inactivity.

Note: Once you've paired, if you pause the party for 15 minutes or more the Jam Street will automatically shut off to preserve battery power.

### ALLOW US TO SHED SOME LIGHT

	What It Looks Like	What It Means
CHARGE	Flashing Red	Low Battery
	RED (when plugged in)	Charging
	LED OFF (fully charged)	Ready to Party
Bluetooth	Quick Flash BLUE	Pairing Mode
	Slow Flash BLUE	Connected
	RED	Line-in Mode



### HOOKING UP OLD SCHOOL AUDIO, JACK

1. Plug one end of the cord into the speaker and the other into the headphone jack on your device.
2. Turn on the speaker.
3. Hit PLAY on your device and crank it up—or down if you're lame.

You'll have to play and pause the music from your device, not your speaker. No problem. You're there anyway, right?

### HELLO? SPEAKERPHONE? YES!

When friends call asking to join the party—and you know they will—answer the phone without disconnecting from your JAM Street. Yes, that's right. Your speaker is a speakerphone too. How amazing is that?

Here's how it works:

1. Make sure your phone and speaker are connected through Bluetooth and not on a "break."
2. Answering and ending a call works the same way: simply click the PLAY/PAUSE button on your Street.

3. If you'd rather not talk, hold down the PLAY/PAUSE button on your Street for three seconds to ignore the call.

THE COOLEST PART: The Street knows when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Street automatically does its hands-free thing. Isn't it refreshing to know your speaker totally gets you?

## THE VOICE FROM WITHIN

When your JAM Street isn't rocking out, it can tell you all sorts of things it's doing: when it's powering on, ready to pair, paired, ignoring a call, ending a call, charging and powering off.

Just like the global gadget it is, your speaker toggles between several languages or no language at all. Your speaker can parlay with you in English, Spanish, French, or

Portuguese. But, making the change is as simple as poking the included Language Selector Pin, a paperclip, safety pin or other thin object (is there another one?) into the small hole on the bottom. Click through until the speaker starts speaking your language.

## LITTLE BIT OF WATER? NO WORRIES.

The smart folks who made this speaker designed it to keep the party going through just about anything, even water. (They call it IPX4.) But those designers aren't miracle workers. Doing something like sending your speaker for a swim in the deep end will fill those holes you need for incredible sound with water—and that's just not gong to bode well for anyone or anything. Also, remember to keep the back flap flush with the speaker for the best protection.

## COMING CLEAN

A soft, dry towel is all you need to clean off your speaker. Using water, harsh cleaners or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

## STUFF THE GOVERNMENT MAKES US SAY

### FCC Disclaimer:

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by HMDX could void the user's authority to operate this equipment.

## ONE YEAR LIMITED WARRANTY

For detailed Warranty Instructions and Information visit: <http://www.jamaudio.com/customer-support/warranty-1yr>

To obtain warranty service on your Jam product, contact a Consumer Relations Representative by telephone at 1-888-802-0040 or email [cservice@jamaudio.com](mailto:cservice@jamaudio.com) for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am - 7:00pm EST Monday-Friday.

- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to Smartphones, iPod/MP3 player or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.

## STUFF OUR LAWYERS MAKE US SAY

### IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING

- **WARNING:** Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

## A MESSAGE FROM THE ENVIRONMENT

### WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province and country guidelines.

This product contains small parts that may present a choking hazard for young children.

CAUTION: All servicing of this product must be performed by authorized Jam Audio Service Personnel only

Note: The most up-to-date version of the Jam Street User Guide can always be found at [www.jamaudio.com](http://www.jamaudio.com)

Por manual de instrucciones e información de garantía en español visítenos en [www.jamaudio.com](http://www.jamaudio.com)

© 2014 HMDX. All Rights Reserved.  
IB-HXP710

Follow JamAudio on Facebook, Twitter, Spotify & Soundcloud  
to feed your Jam with weekly playlists of hot new music.